



DirectFix

We Provide the Parts - You Fix It

INSTALLATION DIRECTIONS IPHONE 4 ORIGINAL REPLACEMENT BATTERY IP-2414



Sim Card
Ejection
Tool IP-2292



Mini
Philips
Driver XX2240



Case
Opener
Tool XX1521



Step #1

Use the simcard ejection tool as pictured to eject the simcard tray.



Step #2

Remove the 2 case screws using the mini screwdriver. This will allow the back case to be removed.



Step #3

The back case will slide up as shown. When you feel resistance, lift the back cover and set aside.



Step #4

The battery connector has one screw. Remove using mini screwdriver.



Step #5

After removing the screw from the battery connector the battery connector can be removed.



Step #6

Match the position and orientation of the original battery for the replacement process.



Step #7

Reconnect the battery to the motherboard and fasten by replacing the screw.



Step #8

Replace the back of the phone as pictured aligning tabs with the inside of the case. Case will snap into place by sliding down slightly once aligned.



Step #9

Replace the two case screws which hold the back of the case to the main case.



Step #10

Replace the simcard and simcard tray as pictured to complete the assembly.